



## GENERAL DESCRIPTION

Junckers Professional 625 is a quick-drying, 2-component, hard-wearing lacquer for professional use on wooden floors in high traffic commercial and residential areas.

The product is used on both previously sealed as well as on untreated or sanded floors.

Compared to similar products Junckers Professional 625 contains solvents with milder odour and solvency power.

## PRODUCT DESCRIPTION

**Product:** 2-component, acid-curing lacquer.

**Package sizes incl. hardener:** 1 + 0.04 litre, 5 + 0.2 litre, 10 + 0.4 litre.

**Appearance:** Colourless film when dry.

**Gloss:** Matt, Silk or Gloss.

## TECHNICAL DATA

**Mixing:** 25 parts of lacquer to 1 part of Hardener.

**Before application:**

Stir/shake the lacquer thoroughly until any settled product has been stirred/shaken in.

Pour hardener and stir/shake the lacquer thoroughly again, minimum 45 seconds.

After adding hardener leave for 10 minutes.

Stir/shake the lacquer again prior to use, minimum 45 seconds.

**Pot-life:** 24 hours at 20° C and 50 % RH.

**Coverage:** 10 m<sup>2</sup> per litre.

**Application tools:** Brush, mohair roller, air/airless spray.

Don't apply by pouring out the lacquer directly on the floor.

**Substrate temperature:** Minimum 15° C.

**Dilution:** Delivered ready for use. Dilution is not recommended.

**Drying time:**

Recoating: 1½ hours.

Light traffic: 24 hours.

Fully cured after 3 days

**Cleaning of tools:** White spirit.

**Storage:** Lasts for 2 years if unopened and stored at 20° C.

## SYSTEM RECOMMENDATION

### High and low traffic in commercial and residential areas:

1 coat Junckers Professional 625 Matt\* 10 m<sup>2</sup>/litre + 1 coat Junckers Professional 625 in needed gloss 10 m<sup>2</sup>/litre.

### Note \*

A more full-bodied finish is obtained when Junckers Professional 625 in Matt is used as primer.

## DIRECTION FOR USE

### Untreated/Sanded Floors:

Ensure that the surface is absolutely clean, dry and free from dust, wax, grease, polish etc. Sand the surface to remove dirt and irregularities. Vacuum thoroughly and wipe off with a well wrung cloth and clean water.

Prime with one coat of Junckers Professional 625 and allow drying.

Sand with sand paper grain 150-180 along the fibres of the wood. Vacuum sanding dust and wipe off with a well wrung cloth and clean water.

Apply one finishing coat of Junckers Professional 625.

### Previously sealed floors:

Machine sand by first using sandpapergrit 24-36 to strip old coats. Then remove abrasion marks using grit 60-80.

Finally, use grit 120-150 to obtain a completely smooth surface. Vacuum thoroughly and wipe off with a well wrung cloth and clean water.

Apply a coat of Junckers Professional 625 and allow drying.

Sand with fine paper (grit 150-180) along the fibres of the wood. Vacuum sanding dust and wipe off with a well wrung cloth and clean water.

Apply a further coat of Junckers Professional 625.

## IMPORTANT

Before use of the product, read the label on the container carefully and observe the advised precautionary safety measures.